

MODEL	FORCE [N]	POWER SUPPLY	DESCRIPTION
MVE522	2200	24Vac/dc	long yoke, modulating/ floating control
MVE522S	2200	24Vac/dc	short yoke, modulating/ floating control



APPLICATION AND USE

MVE522 is a flexible electro mechanical actuator for the control of two and three-way globe valves in:

- heating and cooling systems;
- Air Handling Units;
- district heating plants;
- industrial temperature control systems.

The actuator can be controlled either by a proportional (modulating) signal or by an increase/decrease (Floating) signal.

It is easy to mount and connect the actuator. Direct mounting is possible to any CONTROLLI flanged valve. Linkage kits are available for CONTROLLI threaded valves as well as for valves of other manufacturers (table p. 3). The actuator has a fine resolution (500 steps on the full stroke range) for exacting fluid control and it is able to self-calibrate on a different stroke without the need of any user action (this function is DIP switch selectable on the field).

MVE522 has intelligent behaviour and alarm functionality in case of unexpected operation, feedback of alarms to the user is provided by LEDs (GREEN and RED) on the control board.

N.B.: Do not use the actuator if not coupled with its relating valve.

OPERATION

The actuator translates the control signal (modulating or 3 point floating) from the controller into a valve position. A modern brushless DC motor in the actuator drive a gear train and a worm gear – screw jack mechanism convert the motor revolutions into accurate and repeatable linear movements.

Controlli S.p.A. 16010 Sant'Olcese (GE) Tel. 010 73 06 1 Fax. 010 73 06 870/871 www.controlli.eu

Control Signal

MVE522 can be controlled by one of 2 main control types:

- 3 point floating;
- Modulating (or proportional) signal with filed selectable range (e.g., 0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc and 4-20mA).

Manual Override

There is a manual operation handle on the actuator. When it is lowered (manual override ON), the power supply to the motor power stage circuitry is cut and the motor stops. The actuator can be operated manually and the valve positioned accordingly.

The manual override lever stays in position until it is raised again, then board and motor will be powered again. At the end of this operation the actuator moves to initial position (on the basis of DIP n. 1 setting) then it follows the control signal. When the manual override is engaged the GREEN and the RED LED are ON.

Manual operation handle can also be used to modify any DIP switch setting or as re-set function after any alarm occurrence.

The actuator is supplied with the manual override lowered (ON). It is not necessary to remove power supply to modify DIP switches setting.

Position Feedback

The actuator utilizes a 2-10Vdc position feedback (look at DIP n. 1 setting).

Calibration


The actuator has both auto and manual stroke calibration, DIP n. 7.

In factory delivery the auto stroke calibration is enabled – manual calibration is not necessary unless maintenance is required on the valve or certain alarm functions are desired.

End Point Auxiliary Switches (with accessory DMVE)

End point switches change over when the valve is fully open or closed. They are free contacts with 24V AC/DC, 4A max voltage on terminals. End point switches can be utilized to indicate valve stroke end positions and for relay control of additional plant equipment. When the actuators are controlled individually or in sequence, it is possible to use the end switches to toggle when the valve is fully open or fully closed. The auxiliary switch position according to control signal (Y) is shown in the picture below.

Control signal (Y)	Relay KC1	Relay KC2
0-0,5Vdc	KC1 to K2	KC2 to K3
0,5-9,5Vdc	KC1 to K1	KC2 to K3
9,5-10Vdc	KC1 to K1	KC2 to K4



Diagnostic

The actuator is provided with a self diagnostic algorithm able to detect faulty conditions:

- stroke calibration out of range 5-60mm;
- unexpected stall condition (e.g. valve stuck or extra stroke due to actuator link loose);
- voltage supply out of range.

These faulty conditions are signalled through the GREEN and RED LED on the electronic board blinking accordingly (see Diagnostic – Alarm Function Table).

TECHNICAL FEATURES

Supply voltage L1 Ln AC: 24Vac ±20% 50-60Hz DC:22-30Vdc (Reference Ln) Power consumption (running) Power consumption (holding) Running time Modulating 5-15mm Modulating 15-25mm Modulating 25-60mm Floating Transformer Size [VA] Stroke 5-60mm (limited to 30mm for MVE.S) Force [N] 2200 Duty cycle Max 50%/60 minutes voltage 0-10Vdc - impedance > 100kΩ (range: 0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) Sigital inputs Y1 Y2 Connection to L1 or Ln when powered in AC connection to Ln only when powered in DC Voltage 16Vdc ± 0.5Vdc Max load 25mA, voltage 2-10Vdc (0-100%) Mumber of cycles of manual action Number of cycles of automatic action Type of action Type of movement Room temperature Room Humidity Protection degree Nema 2 (*) / IP54 (**)		MVE522 MVE522S		
Power consumption (holding) 10VA / 4W	Supply voltage L1 Ln			
Running time Modulating 5-15mm Modulating 25-60mm Floating		25VA / 10W		
Modulating 5-15mm 60s Modulating 15-25mm 60s Modulating 25-60mm 50 Floating 50 Stroke 5-60mm (limited to 30mm for MVE.S) Force [N] 2200 Duty cycle max 50%/60 minutes Analogue input Y M voltage 0-10Vdc - impedance > 100kΩ (range: 0-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) 500Ω (range 4-20mA) Digital inputs Y1 Y2 connection to L1 or Ln when powered in AC connection to Ln only when powered in DC Voltage 16Vdc ± 0,5Vdc max load 25mA, Voltage 2-10Vdc (0-100%) max load 2mA Number of cycles of manual action 6.000 Number of cycles of automatic action 100.000 Type of action type 1 Type of movement linear Room temperature operation -10T55°C; storage -20T55°C Room Humidity max 90% R.H.		10VA / 4W		
Modulating 15-25mm Modulating 25-60mm60sFloating50Stroke5-60mm (limited to 30mm for MVE.S)Force [N]2200Duty cyclemax 50%/60 minutesAnalogue input Y Mvoltage 0-10Vdc - impedance > 100kΩ (range: 0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) 500Ω (range 4-20mA)Digital inputs Y1 Y2connection to L1 or Ln when powered in AC connection to Ln only when powered in DCOutput V+voltage 16Vdc ± 0,5VdcMumber of cycles of manual action4.000Number of cycles of automatic action100.000Type of actiontype 1Type of movementlinearRoom temperatureoperation -10T55°C; storage -20T55°CRoom Humiditymax 90% R.H.	Running time			
Modulating 25-60mm Floating Transformer Size [VA] 50 Stroke 5-60mm (limited to 30mm for MVE.S) Force [N] 2200 Duty cycle max 50%/60 minutes Analogue input Y M Voltage 0-10Vdc - impedance > 100kΩ (range: 0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) Digital inputs Y1 Y2 Connection to L1 or Ln when powered in AC connection to Ln only when powered in DC Output V+ Voltage 16Vdc ± 0,5Vdc max load 25mA, Voltage 2-10Vdc (0-100%) max load 2mA Number of cycles of manual action 100.000 Number of cycles of automatic action 1ype of action 1ype of movement Room temperature operation -10T55°C; storage -20T55°C Room Humidity max 90% R.H.	Modulating 5-15mm			
Floating Floating Transformer Size [VA] 50	Modulating 15-25mm	203		
Transformer Size [VA] Stroke 5-60mm (limited to 30mm for MVE.S) Force [N] 2200 Duty cycle max 50%/60 minutes voltage 0-10Vdc - impedance > 100kΩ (range: 0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) 500Ω (range 4-20mA) Digital inputs Y1 Y2 connection to L1 or Ln when powered in AC connection to Ln only when powered in DC voltage 16Vdc ± 0,5Vdc max load 25mA, voltage 2-10Vdc (0-100%) max load 2mA Number of cycles of manual action Number of cycles of automatic action Type of action Type of movement Room temperature Room Humidity max 90% R.H.	Modulating 25-60mm	6US		
Stroke 5-60mm (limited to 30mm for MVE.S) Force [N] 2200 Duty cycle max 50%/60 minutes Voltage 0-10Vdc - impedance > 100kΩ (range: 0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) 500Ω (range 4-20mA) Digital inputs Y1 Y2 connection to L1 or Ln when powered in AC connection to Ln only when powered in DC Voltage 16Vdc ± 0,5Vdc max load 25mA, Voltage 2-10Vdc (0-100%) max load 2mA Number of cycles of manual action Number of cycles of automatic action Type of action Type of movement Room temperature Room Humidity max 90% R.H.	Floating			
Force [N] Duty cycle max 50%/60 minutes voltage 0-10Vdc - impedance > 100kΩ (range: 0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) S00Ω (range 4-20mA) Digital inputs Y1 Y2 connection to L1 or Ln when powered in AC connection to Ln only when powered in DC voltage 16Vdc ± 0,5Vdc Output V+ max load 25mA, voltage 2-10Vdc (0-100%) max load 2mA Number of cycles of manual action Number of cycles of automatic action Type of action Type of movement Room temperature Room Humidity voltage 2-10Tdc (0-100%) 100.000 rype 1 linear operation -10T55°C; storage -20T55°C max 90% R.H.	Transformer Size [VA]	50		
Duty cycle max 50%/60 minutes Analogue input Y M voltage 0-10Vdc - impedance > 100kΩ (range: 0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) Digital inputs Y1 Y2 connection to L1 or Ln when powered in AC connection to Ln only when powered in DC Output V+ voltage 16Vdc ± 0,5Vdc Max load 25mA, voltage 2-10Vdc (0-100%) max load 2mA Number of cycles of automatic action 6.000 Type of action type 1 Type of movement linear Room temperature operation -10T55°C; storage -20T55°C Room Humidity max 90% R.H.	Stroke	5-60mm (limited to 30mm for MVE.S)		
Analogue input Y M voltage 0-10Vdc - impedance > 100kΩ (range: 0-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) 500Ω (range 4-20mA) Digital inputs Y1 Y2 connection to L1 or Ln when powered in AC connection to Ln only when powered in DC Voltage 16Vdc ± 0,5Vdc Murput U max load 25mA, Voltage 2-10Vdc (0-100%) max load 2mA Number of cycles of manual action 6.000 Number of cycles of automatic action 100.000 Type of action type 1 Type of movement linear Room temperature operation -10T55°C; storage -20T55°C Room Humidity max 90% R.H.	Force [N]	2200		
Analogue input Y M 0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc) 500Ω (range 4-20mA) Digital inputs Y1 Y2 connection to L1 or Ln when powered in AC connection to Ln only when powered in DC Output V+ voltage 16Vdc ± 0,5Vdc Max load 25mA, voltage 2-10Vdc (0-100%) Mumber of cycles of manual action 6.000 Number of cycles of automatic action 100.000 Type of action type 1 Type of movement linear Room temperature operation -10T55°C; storage -20T55°C Room Humidity max 90% R.H.	Duty cycle	max 50%/60 minutes		
Connection to Ln only when powered in DC Voltage 16Vdc ± 0,5Vdc rank load 25mA, Voltage 2-10Vdc (0-100%) Mumber of cycles of manual action Number of cycles of automatic action Type of action Type of movement Room temperature Room Humidity Voltage 16Vdc ± 0,5Vdc rank load 25mA, Voltage 2-10Vdc (0-100%) 6.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000 100.000	Analogue input Y M	0-10Vdc, 2-10Vdc, 0-5/2-6Vdc, 5-10/6-10Vdc)		
Output V+ max load 25mA, voltage 2-10Vdc (0-100%) max load 2mA Number of cycles of manual action Number of cycles of automatic action Type of action Type of movement Room temperature Room Humidity max 90% R.H.	Digital inputs Y1 Y2			
Max load 25mA, Voltage 2-10Vdc (0-100%) Mumber of cycles of manual action Number of cycles of automatic action Type of action Type of movement Room temperature Room Humidity Movement Max load 2mA 6.000 100.000 100.000 1ype 1 Inear Operation -10T55°C; storage -20T55°C	Output V+	voltage 16Vdc ± 0,5Vdc		
Output U max load 2mA Number of cycles of manual action 6.000 Number of cycles of automatic action 100.000 Type of action type 1 Type of movement linear Room temperature operation -10T55°C; storage -20T55°C Room Humidity max 90% R.H.	33,63.	max load 25mA,		
Number of cycles of manual action Number of cycles of automatic action Type of action Type of movement Room temperature Room Humidity max 90% R.H.		voltage 2-10Vdc (0-100%)		
manual action Number of cycles of automatic action Type of action Type of movement Room temperature Room Humidity S.000 100.000 100.000 type 1 Iinear Room 2005 Storage -20155°C	Output U	max load 2mA		
automatic action Type of action Type of movement Room temperature Room Humidity Type of movement Iinear Operation -10T55°C; storage -20T55°C Room Humidity Max 90% R.H.		6.000		
Type of movement linear Room temperature operation -10T55°C; storage -20T55°C Room Humidity max 90% R.H.		100.000		
Room temperature operation -10T55°C; storage -20T55°C Room Humidity max 90% R.H.	Type of action	type 1		
Room Humidity max 90% R.H.	Type of movement	linear		
	Room temperature	operation -10T55°C; storage -20T55°C		
Protection degree Nema 2 (*) / IP54 (**)	Room Humidity	max 90% R.H.		
^	Protection degree	Nema 2 (*) / IP54 (**)		
Insulation class	Insulation class			
FR4 (material) PLC (Performance Level Categories) = 3 Printed Circuit Board PTI (Proof Tracking Index) = 175 - 249V CTI (Comparative Tracking Index) = PTI Pollution Degree = 2	Printed Circuit Board	PLC (Performance Level Categories) = 3 PTI (Proof Tracking Index) = 175 - 249V CTI (Comparative Tracking Index) = PTI		
Standard Emission/Immunity EMC 2014/30/UE according to EN 61326-1:2013 standard	Standard	Emission/Immunity EMC 2014/30/UE according to EN 61326-1:2013 standard		
Material housing: aluminium - cover: ABS plastic	Material	housing: aluminium - cover: ABS plastic		
Colour aluminium / white	Colour			
Weight [kg] 1,7 (MVE5xx); 1,6 (MVE5xx\$)	Weight [kg]			
Date code yy/ww		, , , ,		


*To guarantee IP54 protection

Insert the actuator cable in the PG13,5 cable gland (not supplied)




ASSEMBLING

The actuator can be mounted with any orientation but never up-side down. When the fluid temperature exceed 120°C the actuator shall be mounted leaning 45°.



To mount the actuator on to a valve, position the valve stem to the bottom of its travel, slide the actuator onto the valve neck, adjusting with the manual override the screw jack position so the square nut on the valve spindle fits into the groove on the cross bar. Then slide the brace into the groove on the valve neck and secure the nuts.



See mounting instructions for full details (MVE_DIM223).

MAINTENANCE

The actuator is free of maintenance.

ACCESSORIES

DMVE	End point auxiliary switches (electrical rate 24V AC/DC,
	4A max)

248 Stem heater (suggested when the fluid temperature is below 0°C) *

GMVE Thermal insulation for MVE actuators *
GMVE.S Thermal insulation for MVE.S actuators *

* It is not possible to install both thermal insulation (Gxxxx) and stem heaters.

Linkage	MVE	MVES		
Current Controlli valves (except for 2TGB.F/3TGB.F PN16)	(not required)	/		
2TGB.F/3TGB.F PN16	/	(not required)		
Controlli valves with threaded M40 connections (except for VSB/VMB/VSBF/VMBF PN16)	AG51	/		
VSB/VMB/ VSBF/VMBF PN16	AG52	AG63		
Other manufacturers				
Landis *	AG70-10 AG70-14	/		
Danfoss (VR/VF (S) models)	AG60-07	/		
TAC DN15-V298	AG 60-08	/		
TAC DN15-V2XX/V3XX	AG 60-09	/		
Honeywell**	AG 60-10	/		
Airtek	AG 60-11/ AG60-12	/		
Johnson Controls code VB7816- 2111	AG 66	/		
Johnson Controls code BM-3018- 3300	AG 67	/		
Tac Venta	(not required)	1		
(/) this model can not be assemble	<u> </u>			
(*) AG70-10 for valves having stem Ø 10mm				


(*) AG70-10 for valves having stem Ø 10mm AG70-14 for valves having stem Ø 14mm

(**) valid for the following models: M6: V176A. B, V538C 1/4": V5011A

ELECTRIC CONNECTIONS


Remove the cover screw with a screwdriver and then remove the cover as shown in the picture beside.

The actuator is equipped with a 8 poles removable terminal block; the each pole of the plug is clearly marked and the same label are reported on the electronic board. Before powering up the actuator make sure the plug is properly connected to the board and the label on the plugs and on the board match.



Use PG13,5 cable gland (not supplied).







Label	Description	Function	Cable type	Max wire length	
L1	24Vac/dc	Power	AWG 16 (min	75m	
Ln	0V	supply	1,5mm²)	75111	
Y	0-10Vdc	Modulating control	AWG 20 (min 0,5mm² - max	200m	
М	0V (common)	input	1,5mm ²)	ZUUITI	
Y1	Open	Floating control	AWG 20 (min 0,5mm² - max 1,5mm²)	200m	
Y2	Close	input			
V+	16Vdc	Voltage	AWG 20 (min	200m	
М	0V (common)	output max 25mA	0,5mm² - max 1,5mm²)	200M	
U	2-10Vdc	Feedback	AWG 20 (min	000	
М	0V (common)	output signal	0,5mm² - max 1,5mm²)	200m	

Note: To avoid damages to electronic components caused by the PCB bending, do not press too much while fixing the terminal block.


Matching between MVE terminal block and others Controlli actuators




3 point floating control (sink connection)



3 point floating control (source connection)




Modulating control (0-10Vcc)




N.B.: M and Ln signals are internally connected.

(*) MVE contain a single half-wave rectifier power supply. They must not be powered with transformers that are used to power other devices using not isolated double half-wave rectifier power supply.

Set the DIP switches according to the tables here below. Power down and power up again the actuator or act on the manual override to be sure that settings will be recognized.





DIP switch	OFF	ON
1	U= feedback Direct Action U = 2V U = 10V	U=10V U= feedback U = 2V
2	Modulating Control (MOD) (Input between Y [+] and M [-])	3 point floating (INC) (Y1 open-extend , Y2 close-retract connected L1 or Ln if powered in Vac; if powered in Vdc connected necessarily to Ln)
3	-	Selection of sequence mode, control range defined by DIP n. 5
4	Modulating Control 0-10Vdc (DIP n. 2 OFF only)	Modulating Control 2-10Vdc (DIP n. 2 OFF only)
5	Sequence Control 0-5Vdc with DIP n. 4 OFF only Sequence Control 2-6Vdc with DIP n. 4 ON only (DIP n. 3 ON only)	Sequence Control 5-10Vdc with DIP n. 4 OFF only Sequence Control 6-10Vdc with DIP n. 4 ON only (DIP n. 3 ON only)
6	Voltage Input Signal (input between Y [+] and M [-])	Current Input Signal 4-20mA (input between Y [+] and M [-]). In this case DIP n. 4 must be set to ON.
7	Automatic Calibration: the actuator updates the stroke range every time an unexpected mechanical stop is detected for at least 10s	Manual Calibration: the actuator calibration is started moving the DIP from OFF to ON or vice versa. With DIP in ON in case of extra stroke or if an unexpected endpoint is detected, the actuator will never update the stroke


N°	LEDs behaviour	Error	Actuator use	Actuator	behaviour	Typical trouble shooting condition	Reset procedure
				Automatic calibration (DIP N. 7 OFF)	Manual calibration (DIP N. 7 ON)		
1	RED ON	Valve stroke less than 5mm	Calibration/first installation	The actuator pushes/pulls 2 times (unexpected stall) trying to remove the possible obstacle. After 2 tries an alarm is signalled and the actuator moves to initial position and does not respond to control signal. Stroke value is not updated because out of range	The actuator pushes/pulls 2 times against endpoint during calibration and the actuator moves to the initial position and then it does not respond to the control signal. The actuator keeps the previous stroke	Valve with a stroke length lower than 5mm	Remove power and power up again
2	RED quick blinking + GREEN ON	Stroke longer than 60mm	Calibration/first installation	The actuator exits the 60mm stroke range and it moves toward the new stroke limit signalling an anomaly. The actuator pushes/pulls 2 times against the new stroke limit, then it goes back to the initial position still signalling the anomaly until it is not within 60mm. The actuator does not calibrate the stroke after 10s (wrong range)	The actuator exits the 60mm stroke range and it moves toward the new stroke limit signalling an anomaly. The actuator pushes/pulls 2 times against the new stroke limit, then it goes back to the initial position still signalling the anomaly until it is not within 60mm. The actuator does not calibrate the stroke after 10s (wrong range)		Remove power and power up again
3	RED Quick Blinking	Unexpected stall within the calibrated stroke range	normal operation	The actuator tries 5 times against the new stall condition and then after 10s the actuator updates the new stroke length	The actuator tries 5 times against the new stall condition. At the end of the attempts the fault will be signalled. The actuator does not update the new stroke length, but after 60s makes other attempts to verify the stall condition	Valve stuck	Inverted control signal
4	RED Quick Blinking	Stroke longer than expected	Normal operation	The actuator moves toward the new stall condition with a lower speed; after 10s the actuator updates the new stroke value	The actuator moves toward the new stall condition with a lower speed; after 10s the actuator does not update the new stroke value	Stem connection loose or valve damaged	Inverted control signal
5	RED slow	Low Power	Normal	The actuator is still working but performance cannot be	The actuator is still working but performance cannot be	Wrong transformer size	Correct
	Blinking	Voltage	operation	guaranteed	guaranteed	2. Unstable power	Voltage Power
6	RED slow Blinking	High Power Voltage	Normal operation	The actuator is still working but performance cannot be guaranteed	The actuator is still working but performance cannot be guaranteed	Wrong transformer size 2. Unstable power	Correct Voltage Power

Page 6

STANDARD LEDs BEHAVIOUR

N°	LED behaviour	Actuator status
1	GREEN ON	The actuator arrived at the extreme point of the stroke read
2	GREEN BLINKING	The actuator arrived at the intermediate point of the stroke read
3	RED GREEN BLINKING	The actuator is reading the stroke or it is going to initial position
4	RED GREEN ON	Manual control ON, the actuators ignores the control signal. ATTENTION! The electronic board is electrically supplied

DIMENSIONS [mm]



The performances stated in this sheet can be modified without any prior notice

